

Tormek SVX150 Scissors Jig-



The SVX150 is for scissors and shears. The scissors are mounted in a holder, which supports them on an adjustable plate so you can follow the individual convex shape of the scissors. Also useful for portable electric hand planer blades.

Auckland
19 Allens Road, East Tamaki
Auckland 2013
Ph (09) 271 7700
Fax (09) 271 7728

Christchurch
159 Ferry Road, Waltham
Christchurch 8011
Ph (03) 366 2013
Fax (03) 366 2021

Call free: 0800 522 577
Copyright © 2025 W & R Jack Limited.



Tormek SVX150 Scissors Jig-



Overview and features

Auckland
19 Allens Road, East Tamaki
Auckland 2013
Ph (09) 271 7700
Fax (09) 271 7728

Christchurch
159 Ferry Road, Waltham
Christchurch 8011
Ph (03) 366 2013
Fax (03) 366 2021

Call free: 0800 522 577
Copyright © 2025 W & R Jack Limited.

