

# Tormek WM200 AngleMaster-



The AngleMaster sets and measures the edge angle. It is adjustable to any stone diameter from Ø 250mm or 10" down to Ø 150mm or 6", and measures from 10° to 75°.

Handy magnets make for easy storage, particularly against the body of your T7

**Auckland**  
19 Allens Road, East Tamaki  
Auckland 2013  
Ph (09) 271 7700  
Fax (09) 271 7728

**Christchurch**  
159 Ferry Road, Waltham  
Christchurch 8011  
Ph (03) 366 2013  
Fax (03) 366 2021

**Call free: 0800 522 577**  
Copyright © 2025 W & R Jack Limited.



# Tormek WM200 AngleMaster-



## Overview and features

This patented AngleMaster has two functions: You can use it to set the jig to the grindstone so that it grinds your tool to any desired edge angle from 10° to 75°, and you can use it to measure an existing edge angle on a tool.

It is designed to work on any grindstone diameter from 250mm (10") down to 150mm (6"). You achieve an exact setting, irrespective of the degree of stone wear.

### Auckland

19 Allens Road, East Tamaki  
Auckland 2013  
Ph (09) 271 7700  
Fax (09) 271 7728

### Christchurch

159 Ferry Road, Waltham  
Christchurch 8011  
Ph (03) 366 2013  
Fax (03) 366 2021

**Call free: 0800 522 577**

Copyright © 2025 W & R Jack Limited.

