



Give your scissors the edge they deserve - with professional precision on your Tormek.

The SC-60 Scissors Jig lets you sharpen most types of scissors and shears, from everyday kitchen scissors to heavy-duty hedge shears. The design features a quick 60-degree angle setting, a clamping that grips for enhanced stability and reduced vibration and a hexagonally patterned support plate for low friction.

The SC-60 Scissors Jig fits the Tormek T-8, Tormek T-4 and Tormek T-2 Pro Kitchen Knife Sharpener. No more tossing dull scissors - with the SC-60 Scissors Jig even your oldest scissors will make the cut. Faster, easier, and more precise.

The SC-60 Scissors Jig comes fully assembled and ready to use.

- Instructions for the SC-60 Scissors Jig.
- Mounting plate for scissors/shears.
- Hexagonally patterned support plate.



SC-60 Faster, easier, and more precise.

The SC-60 Scissors Jig lets you sharpen most types of scissors and shears.

Overview and features

Auckland
19 Allens Road, East Tamaki
Auckland 2013
Ph (09) 271 7700
Fax (09) 271 7728

Christchurch
159 Ferry Road, Waltham
Christchurch 8011
Ph (03) 366 2013
Fax (03) 366 2021

Call free: 0800 522 577
Copyright © 2026 W & R Jack Limited.

