

# Tormek SVX150 Scissors Jig-



The SVX150 is for scissors and shears. The scissors are mounted in a holder, which supports them on an adjustable plate so you can follow the individual convex shape of the scissors. Also useful for portable electric hand planer blades.

**Auckland**  
19 Allens Road, East Tamaki  
Auckland 2013  
Ph (09) 271 7700  
Fax (09) 271 7728

**Christchurch**  
159 Ferry Road, Waltham  
Christchurch 8011  
Ph (03) 366 2013  
Fax (03) 366 2021

Call free: 0800 522 577  
Copyright © 2025 W & R Jack Limited.



# Tormek SVX150 Scissors Jig-



## Overview and features

**Auckland**  
19 Allens Road, East Tamaki  
Auckland 2013  
Ph (09) 271 7700  
Fax (09) 271 7728

**Christchurch**  
159 Ferry Road, Waltham  
Christchurch 8011  
Ph (03) 366 2013  
Fax (03) 366 2021

**Call free: 0800 522 577**  
Copyright © 2025 W & R Jack Limited.

