

Tormek WM200 AngleMaster



The AngleMaster sets and measures the edge angle. It is adjustable to any stone diameter from \varnothing 250mm or 10" down to \varnothing 150mm or 6", and measures from 10° to 75°.

Handy magnets make for easy storage, particularly against the body of your T7.

Auckland
19 Allens Road, East Tamaki
Auckland 2013
Ph (09) 271 7700
Fax (09) 271 7728

Christchurch
159 Ferry Road, Waltham
Christchurch 8011
Ph (03) 366 2013
Fax (03) 366 2021

Call free: 0800 522 577
Copyright © 2021 W & R Jack Limited.



Tormek WM200 AngleMaster



Overview and features

This patented AngleMaster has two functions: You can use it to set the jig to the grindstone so that it grinds your tool to any desired edge angle from 10° to 75°, and you can use it to measure an existing edge angle on a tool.

It is designed to work on any grindstone diameter from 250mm (10") down to 150mm (6"). You achieve an exact setting, irrespective of the degree of stone wear.

Auckland

19 Allens Road, East Tamaki
Auckland 2013
Ph (09) 271 7700
Fax (09) 271 7728

Christchurch

159 Ferry Road, Waltham
Christchurch 8011
Ph (03) 366 2013
Fax (03) 366 2021

Call free: 0800 522 577

Copyright © 2021 W & R Jack Limited.

